

Directions for Stacked Receiver Setup

YOU MUST FOLLOW THESE DIRECTIONS BEFORE YOUR RECEIVER WILL WORK. DO NOT FOLLOW THE GUIDED SETUP INSTRUCTIONS.

These instructions are for Model D10 receivers only.

Please follow the instructions below. You will need to have a television connected to your receiver in order to perform the setup. If after you've followed all the instructions and still have a problem, please don't hesitate to call.

Instructions:

1. Connect the cable from the wall to the **SATELLITE IN** on the back of the receiver. Connect the television to the output from the receiver. Plug the power cord into the receiver and your power outlet. Find the access card and insert it into the slot behind the door on the front right of the receiver.
2. Turn on the receiver. At the guided setup screen press the **SELECT** button to get to the next screen.
3. On the front of the receiver press then **MENU** and **DOWN ARROW** buttons **simultaneously** and **hold** until a blank screen with **SEARCHING FOR SATELLITE** appears.
4. Press the **GUIDE** and **DOWN ARROW** buttons simultaneously and hold until the **SERVICE AND DIAGNOSTICS** menu appears.
5. Arrow down to **LNB SELECT** and press the **SELECT** button.
6. You should see that the LNB is set to **UNSTACKED**. Press the **SELECT** button and arrow down to **STACKED**. Press the **SELECT** button.
7. Arrow left and down to **DONE** and press the **SELECT** button. The screen will go black for up to 1 minute and then you should see **DOWNLOADING PROGRAM GUIDE** appear.
8. Once the status bar reaches 100%, call the 800 number below to activate your service.

ALL RECEIVERS MUST BE ACTIVATED (called in) USING YOUR PRE-ASSIGNED DIRECTV ACCOUNT #. Prime Student Housing has this information if you do not already have it.

DIRECTV #800-531-5000 (use your access card # to reference your account) The access card is located in the front compartment of the receiver.

This will need to be done for all new receivers.